

Wrapid Fit | How to guide

Our award-winning Wrap PFDs feature the Wrapid Fit entry system, giving the ease of a front entry PFD yet with the pocket layout and comfort of an over-the-head model. The twin-panel, wrap-around design also allows us to offer a unique fit for women, with the internal chest panel split into three parts, giving unrivalled comfort for female paddlers. The Wrap PFDs are the ultimate ladies specific PFD model.



- Start with all buckles and harness* undone and the PFD open. Bring the outer panel over the inner panel to align the two Velcro squares and join these together. Fasten the zip - use the thumb tab on the bottom of the zip to align the zipper and the teeth initially.
- Starting from the waist, connect all buckles, including the top buckle on the shoulder.
- Tighten the waist and side straps to the desired fit. On the River Wrap feed approximately 5cm through the cam buckle and adjust the three bar slider on the opposite side of the PFD to take up any slack.

You can either have a friend adjust your shoulder straps whilst you are wearing the PFD, or adjust them yourself before fitting. Once the shoulders are the correct length, you will not need to adjust them again for future use. *River / Rescue Wrap models only.